

2.4 Control Buttons

The Control Buttons allow appending, inserting, and deleting one or all index lines. The Undo button is useful in cases where an error was made and restoration of the last operation is critical.

Now that you are familiar with the Pulse Composer and Pulse Editor, for a step by step example of how to generate a pulse train please refer to the next tutorial in the series, [Creating Complex Pulses and Pulse Trains Part 3 - How To Simply Design a Pulse Train](#).

For More Information

To learn more about Tabor's ArbConnection and its composers please visit our website Support&Tutorials zone. For more of Tabor's solutions or to schedule a demo, please contact your local Tabor representative or email your request to info@tabor.co.il. More information can be found at our website at www.taborelec.com

© Proprietary of Tabor Electronics Ltd.