



A10150 150 MHz 16 Vp-p Single Channel Wideband Amplifier

User Manual

Rev. 1.1

WARRANTY STATEMENT

Products sold by Tabor Electronics Ltd. are warranted to be free from defects in workmanship or materials. Tabor Electronics Ltd. will, at its option, either repair or replace any hardware products which prove to be defective during the warranty period. You are a valued customer. Our mission is to make any necessary repairs in a reliable and timely manner.

Duration of Warranty

The warranty period for this Tabor Electronics Ltd. hardware is one year, except software and firmware products designed for use with Tabor Electronics Ltd. Hardware is warranted not to fail to execute its programming instructions due to defect in materials or workmanship for a period of ninety (90) days from the date of delivery to the initial end user.

Return of Product

Authorization is required from Tabor Electronics before you send us your product for service or calibration. Call your nearest Tabor Electronics support facility. A list is located on the last page of this manual. If you are unsure where to call, contact Tabor Electronics Ltd. Tel Hanan, Israel at 972-4-821-3393 or via fax at 972-4-821-3388. We can be reached at: support@tabor.co.il

Limitation of Warranty

Tabor Electronics Ltd. shall be released from all obligations under this warranty in the event repairs or modifications are made by persons other than authorized Tabor Electronics service personnel or without the written consent of Tabor Electronics.

Tabor Electronics Ltd. expressly disclaims any liability to its customers, dealers and representatives and to users of its product, and to any other person or persons, for special or consequential damages of any kind and from any cause whatsoever arising out of or in any way connected with the manufacture, sale, handling, repair, maintenance, replacement or use of said products.

Representations and warranties made by any person including dealers and representatives of Tabor Electronics Ltd., which are inconsistent or in conflict with the terms of this warranty (including but not limited to the limitations of the liability of Tabor Electronics Ltd. as set forth above), shall not be binding upon Tabor Electronics Ltd. unless reduced to writing and approved by an officer of Tabor Electronics Ltd.

This document may contain flaws, omissions or typesetting errors. No warranty is granted nor liability assumed in relation thereto. The information contained herein is periodically updated and changes will be incorporated into subsequent editions. If you have encountered an error, please notify us at support@taborelec.com. All specifications are subject to change without prior notice.

Except as stated above, Tabor Electronics Ltd. makes no warranty, express or implied (either in fact or by operation of law), statutory or otherwise; and except to the extent stated above, Tabor Electronics Ltd. shall have no liability under any warranty, express or implied (either in fact or by operation of law), statutory or otherwise.

PROPRIETARY NOTICE

This document and the technical data herein disclosed, are proprietary to Tabor Electronics, and shall not, without express written permission of Tabor Electronics, be used, in whole or in part to solicit quotations from a competitive source or used for manufacture by anyone other than Tabor Electronics. The information herein has been developed at private expense, and may only be used for operation and maintenance reference purposes or for purposes of engineering evaluation and incorporation into technical specifications and other documents, which specify procurement of products from Tabor Electronics.

Table of Contents

Table of Contents.....	3
List of Figures.....	3
Document Revision History.....	4
Acronyms & Abbreviations	5
1 General	8
1.1 A10150 Feature Highlights	8
1.2 Configuration Options	9
1.3 Safety Considerations	9
1.4 Long Term Storage or Repackaging for Shipment	9
2 Introduction	11
2.1 Unpacking and Initial Inspection	11
2.2 Connectors.....	11
2.3 Power Supply	11
2.4 Specifications	11
2.5 Operating Environment	11
2.6 Performance Checks	12
2.7 Supplied Accessories	12
2.8 Installation & Operating Instructions	12
3 Specifications	14
3.1 Input Characteristics.....	14
3.2 Output Characteristics.....	14
3.3 Amplitude	14
3.4 Frequency	15
3.5 Mechanical, Environmental and Maintenance Specifications.....	15
3.5.1 Power Feed	15
3.5.2 Mechanical.....	15
3.5.3 Environmental.....	15
3.5.4 Certifications and Compliances.....	16
3.5.5 Maintenance	16

List of Figures

Figure 1.1 Model A10150.....	9
Figure 2.1 2 x A10150 kit for Dual Channel Unit.....	12
Figure 2.2 Connecting the A10150 to Tabor WX or WS8351/2 Unit	13

Document Revision History

Table Document Revision History

Revision	Date	Description	Author
1.1	5-Jan-21	<ul style="list-style-type: none">• Changed formatting and name from “Quick Start Guide” to “User manual”.	Jakob Apelblat

Acronyms & Abbreviations

Table Acronyms & Abbreviations

Acronym	Description
μs or us	Microseconds
ADC	Analog to Digital Converter
AM	Amplitude Modulation
ASIC	Application-Specific Integrated Circuit
ATE	Automatic Test Equipment
AWG	Arbitrary Waveform Generators
AWT	Arbitrary Waveform Transceiver
BNC	Bayonet Neill–Concelm (coax connector)
BW	Bandwidth
CW	Carrier Wave
DAC	Digital to Analog Converter
dBc	dB/carrier. The power ratio of a signal to a carrier signal, expressed in decibels
dBm	Decibel-Milliwatts. E.g., 0 dBm equals 1.0 mW.
DDC	Digital Down-Converter
DHCP	Dynamic Host Configuration Protocol
DSO	Digital Storage Oscilloscope
DUC	Digital Up-Converter
DUT	Device Under Test
ENoB	Effective Number of Bits
ESD	Electrostatic Discharge
EVM	Error Vector Magnitude
FPGA	Field-Programmable Gate Arrays
FW	Firmware
GHz	Gigahertz
GPIB	General Purpose Interface Bus
GS/s	Giga Samples per Second
GUI	Graphical User Interface

Acronym	Description
HP	Horizontal Pitch (PXIe module horizontal width, 1 HP = 5.08mm)
Hz	Hertz
IF	Intermediate Frequency
I/O	Input / Output
IP	Internet Protocol
IQ	In-phase Quadrature
IVI	Interchangeable Virtual Instrument
JSON	JavaScript Object Notation
KHz	Kilohertz
LCD	Liquid Crystal Display
LO	Local Oscillator
MAC	Media Access Control (address)
MDR	Mini D Ribbon (connector)
MHz	Megahertz
ms	Milliseconds
NCO	Numerically Controlled Oscillator
ns	Nanoseconds
PC	Personal Computer
PCAP	Projected Capacitive Touch Panel
PCB	Printed Circuit Board
PCI	Peripheral Component Interconnect
PXI	PCI eXtension for Instrumentation
PXIe	PCI Express eXtension for Instrumentation
QC	Quantum Computing
Qubits	Quantum bits
R&D	Research & Development
RF	Radio Frequency
RT-DSO	Real-Time Digital Oscilloscope
s	Seconds
SA	Spectrum Analyzer

Acronym	Description
SCPI	Standard Commands for Programmable Instruments
SFDR	Spurious Free Dynamic Range
SFP	Software Front Panel
SMA	Subminiature version A connector
SMP	Subminiature Push-on connector
SPI	Serial Peripheral Interface
SRAM	Static Random-Access Memory
TFT	Thin Film Transistor
T&M	Test and Measurement
TPS	Test Program Sets
UART	Universal Asynchronous Receiver-Transmitter
USB	Universal Serial Bus
VCP	Virtual COM Port
Vdc	Volts, Direct Current
V p-p	Volts, Peak-to-Peak
VSA	Vector Signal Analyzer
VSG	Vector Signal Generator
WDS	Wave Design Studio

1 General

The A10150 is a wideband DC coupled amplifier that combines high output drive and low distortion. At an output of +24dBm (10Vp-p into 50Ω), the -3dB bandwidth is 150MHz. With the output current internally limited to 250mA, the A10150 is fully protected against shorts to ground.

The A10150's small footprint box is especially designed to fit on Tabor's WX series and models WS8351/2 as an add-on option, to boost their power performance above the internal capabilities of 4Vp-p, and amplify them to a maximum of 20Vp-p into 50 ohms, using a fixed gain of x5. 32Vp-p is the maximum amplitude level this amplifier can produce, however, only into high impedance loads.

Idea

- Knowing your source impedance is very important, because the output gain accuracy is calibrated to specific source impedance and therefore, any unmatched load impedance may have an effect on output level accuracy.

Caution!

- Applying the output signal on inductive or capacitive loads may damage the amplifier.

1.1 A10150 Feature Highlights

- 150MHz bandwidth
- High amplitude to 20Vp-p into 50Ω
- Low distortion
- Small footprint, all metal case
- Fast transition time of <1.8ns
- Custom Configuration of:
 - ◆ Gain (x5 or x10)
 - ◆ Maximum output (16Vp-p or 20Vp-p)



Figure 1.1 Model A10150

1.2 Configuration Options

The A10150's standard configuration enables a maximum output voltage of 16Vp-p into 50 ohms and a gain of x5. Custom gain of x10 and maximum voltage of 20Vp-p into 50 ohms options can be ordered.

Caution!

- This manual has no schematics and no instructions how to modify the amplifier for other configurations as any configuration change, without full engineering supervision, may affect the performance of the amplifier. All options must be specified at the time of your purchase. Reconfiguration of fielded instruments can be done by qualified and trained persons only.
-

1.3 Safety Considerations

The Model A10150 has been manufactured according to international safety standards. The instrument meets EN61010-1 standards for safety of commercial electronic measuring and test equipment for instruments with an exposed metal chassis that is directly connected to earth via the chassis power supply cable.

Caution!

- Do not remove instrument covers when operating the instrument or when the power cord is connected to the mains.
-

Any adjustment, maintenance and repair of an opened, powered-on instrument should be avoided as much as possible, but when necessary, should be carried out only by a skilled person who is aware of the hazard involved.

1.4 Long Term Storage or Repackaging for Shipment

If the A10150 is to be stored for a long period of time or shipped to a service center, proceed as directed below. If repackaging procedures are not clear to you or, if you have questions, contact your nearest Tabor Electronics Representative, or the Tabor Electronics Customer Service Department.

1. Repack the instrument using the wrappings, packing material and accessories originally shipped with the unit. If the original container is not available, purchase replacement materials.
2. Be sure the carton is well sealed with strong tape or metal straps.

3. Mark the carton with the model and serial number. If it is to be shipped, show sending and return address on two sides of the box.

Note

- If the instrument is to be shipped to Tabor Electronics for calibration or repair, attach a tag to the instrument identifying the owner. Note the problem, symptoms, and service or repair desired. Record the model and serial number of the instrument. Show the RMA (Returned Materials Authorization) order as well as the date and method of shipment. ALWAYS OBTAIN AN RMA NUMBER FROM THE FACTORY BEFORE SHIPPING THE UNIT TO TAVOR ELECTRONICS.
-

2 Introduction

2.1 Unpacking and Initial Inspection

Unpacking and handling of the A10150 requires normal precautions and procedures applicable to handling of sensitive electronic equipment. The contents of all shipping containers should be checked for included accessories and certified against the packing slip to determine that the shipment is complete.

2.2 Connectors

The A10150 has two front panel SMA input connectors, normal and complement, which match the Tabor's WX series and WX8351/2 outputs locations. The A10150 normal input should be connected to the normal output of the signal source. The complement input should be connected to the complement output of the signal source as it is terminated to 50 ohms, in order to prevent undesired aberrations from the differential signal source. However, if the signal source does not have a differential output, the A10150 complement output does not have to be connected. At the rear panel the A10150 has one BNC output connector, which outputs the amplified signals and the power DIN-5 input connector, which is fed from a factory supplied power supply.

2.3 Power Supply

The A10150 comes with a factory supplied power supply, which accepts any voltage from 100 to 240Vac and there is no need to select the voltage range between different countries. To avoid potentially hazardous situations, always connect the center pin of the power supply plug to mains ground using the line cord that is supplied with the instrument.

2.4 Specifications

The specifications listed in this manual represent the performance standards or limits against which the A10150 is tested. Specifications apply under the following conditions: output terminated into 50 ohms impedance, after 30 minutes of warm up time, and within a temperature range of 20°C to 30°C. Specifications outside of the temperature range are degraded by 0.1% per °C.

2.5 Operating Environment

The A10150 is intended for indoor use only and should be operated in a clean, dry environment with an ambient temperature within the range of 0 °C to 40 °C.

Caution!

- The A10150 must not be operated in explosive, dusty, or wet atmospheres. Avoid installation of the module close to strong magnetic fields.
-

2.6 Performance Checks

The instrument has been inspected for mechanical and electrical performance before shipment from the factory. It is free of physical defects and in perfect electrical order. Check the instrument for damage in transit and perform the electrical procedures outlined in the section entitled Unpacking and Initial Inspection.

2.7 Supplied Accessories

The A10150 is supplied with a power supply, power cord, two SMA/M to SMA/M connectors to tie the A10150 to the instrument, and in some cases, a “Y” splitter cable to connect two A10150 to the same power supply mains.




Figure 2.1 2 x A10150 kit for Dual Channel Unit

2.8 Installation & Operating Instructions

Being a passive device, there are no controls, nor computer programming required to operate the A10150. The following procedure is recommended for proper installation of the A10150 with the Tabor WX series and WS8351/2 models, however, model A10150 can be used in conjunction with any signal source, simply by using cables to connect to the amplifier:

1. Connect the input terminals to your source, using the supplied SMA/M to SMA/M connectors, as shown in figure 2.
2. Connect the output terminal to your load.
3. Connect the power input terminal to the supplied power supply.

Caution!

- There is no switch control to turn A10150 amplification on and off and therefore, the amplifier is active immediately after you power it up. Always make sure your load is protected from inadvertent power up conditions before you turn on your A10150.
-



Figure 2.2 Connecting the A10150 to Tabor WX or WS8351/2 Unit

3 Specifications

3.1 Input Characteristics

Characteristics	Description
No. of Channels	1, Differential; normal and inverted
Connector	Front panel SMA
Impedance	50Ω
Coupling	DC
Damage Level	6Vp-p (-3V to +3V peaks)

3.2 Output Characteristics

Characteristics	Description
No. of Channels	1
Coupling	DC coupled
Connector	Rear panel BNC
Gain	x5, fixed (x10 gain optional)
Polarity	Normal
Max. Output Current	250mA
Impedance	50Ω ±1%
Protection	Short circuit to case ground, 10s max

3.3 Amplitude

Characteristics	Description
Amplitude	16Vp-p into 50Ω (20Vp-p optional)
Rise/Fall Time	
2V step	<1.8ns (typ.)
10V step	<2.6ns (typ.)
Aberration	
2Vpp	<5%
10Vpp	<10%

3.4 Frequency

Characteristics	Description		
Frequency Range	DC to 150MHz		
Bandwidth (-3dB)			
<2Vpp	200MHz (typ.)		
<10Vpp	150MHz (typ.)		
Harmonics & Non-Harmonic Distortion (typ.)	2Vpp	5Vpp	10Vpp
20MHz	<-59dBc	<-52dBc	<-50dBc
50MHz	<-52dBc	<-45dBc	<-36dBc
100MHz	<-35dBc	<-30dBc	<-40dBc

3.5 Mechanical, Environmental and Maintenance Specifications

3.5.1 Power Feed

Characteristics	Description
Voltage Requirement	±15VDC
Power Consumption	7W
Signal Ground	Grounded to case ground

3.5.2 Mechanical

Characteristics	Description
Dimensions	45 x 30 x 85 mm (W x H x D)
Weight	
Without Package	115 g (standalone)
Shipping Weight	
1 x A10150 Kit	1.25 Kg
2 x A10150 Kit	1.45 Kg

3.5.3 Environmental

Characteristics	Description
Temperature	

Characteristics	Description
Operating	0°C to 40°C
Storage	-40°C to 70°C
Humidity	80% RH, non-condensing

3.5.4 Certifications and Compliances

Characteristics	Description
Safety	IEC61010-1
EMC	IEC 61326-1:2006

3.5.5 Maintenance

Characteristics	Description
Warranty	1 year
Recalibration Period	2 years